


Link do produktu: <https://www.diablosat.pl/pilot-tv-sony-rm-ed009-oryginalny-p-3325.html>



Opis produktu

A black Sony RM-SD10 remote control is shown at an angle. It features a variety of buttons: a green power button at the top, a row of colored buttons (red, green, yellow, blue), a directional pad, and a numeric keypad. The Sony logo and 'RM-SD10' model number are visible at the bottom.

SONY KDL-26P3000
SONY KDL-26P3020
SONY KDL-32P3000
SONY KDL-32P3020
SONY KDL-37P3000
SONY KDL-37P3020
SONY KDL-40P3000
SONY KDL-40P3020
i wiele innych